MC3000 QR Code Scanner

Operating Instructions for Changing Reading Mode to Command Reading

The scanner defaults to automatic induction mode. If you need to set the code scanner to command reading and read the QR code or barcode after sending the reading command, you need to make the following settings, which are only valid for serial ports.

1、First, change the output mode to command reading mode; Scan the setting code below, or send the command below the QR code to change it to command reading.

$100000-AF9D（Command Reading Mode）

2、In Command Reading Mode, There Are Two Ways to Read

①、When scanning the code, send this command to the module ($108000-ADB0) to trigger reading; The reading time is 6 seconds, If it exceeds 6 seconds, you need to resend the read command.

$108000-ADB0（Trigger Read Command）

② When scanning code, send the command ($108001-9E81), and the code scanner will trigger the continuous reading mode. The device will only stop reading when the ($108003-F8E3) stop triggering the read command is sent;

$108001-9E81（Start Triggering Reading）

$108003-F8E3（Stop Triggering Reading）

3. Restore the Automatic Induction Reading Mode.

When you need to change the reading mode back to the original automatic sensing mode, after sending the trigger reading command, the scanner can scan the following setting code or send the automatic sensing mode command ($100004-6359) to the scanner module together with the trigger reading command, so as to restore to the automatic sensing reading mode.

$100004-6359（Automatic Sensing Mode）